

RECEPTION CENTRALE central reception  L x p. 80,5 x H. 110	RECEPTION TERMINALE DX o SX end right or left reception  (Fig. DX / right) L x p. 80,5 x H. 110	ANGOLO ESTERNO 90 CENTRALE central 90 external corner  L127,5 x p. 127,5 x H. 110	ANGOLO ESTERNO 90 TERMINALE DX o SX end right or left 90 external corner  (Fig. DX / right) L127,5 x p. 139,5 x H. 110	ANGOLO INTERNO 90 CENTRALE central 90 internal corner  L93 x p. 93 x H. 110	ANGOLO INTERNO 90 TERMINALE DX o SX end right or left 90 internal corner  (Fig. DX / right) L93 x p. 105 x H. 110	ANGOLO ESTERNO 60 CENTRALE central 60 external corner  L168 x p. 92 x H. 110	ANGOLO ESTERNO 60 TERMINALE DX o SX end right or left 60 external corner  (Fig. DX / right) L176 x p. 92 x H. 110	ANGOLO INTERNO 60 CENTRALE central 60 internal corner  L214 x p. 98,5 x H. 110	ANGOLO INTERNO 60 TERMINALE DX o SX end right or left 60 internal corner  (Fig. DX / right) L215 x p. 101,5 x H. 110
RECEPTION CENTRALE central reception  L x p. 80,5 x H. 110	RECEPTION TERMINALE DX o SX end right or left reception  (Fig. DX / right) L x p. 80,5 x H. 110	ANGOLO ESTERNO 90 CENTRALE central 90 external corner  L139,5 x p. 139,5 x H. 110	ANGOLO ESTERNO 90 TERMINALE DX o SX end right or left 90 external corner  (Fig. DX / right) L139,5 x p. 139,5 x H. 110	ANGOLO INTERNO 90 CENTRALE central 90 internal corner  L105 x p. 105 x H. 110	ANGOLO INTERNO 90 TERMINALE DX o SX end right or left 90 internal corner  (Fig. DX / right) L105 x p. 105 x H. 110	ANGOLO ESTERNO 60 CENTRALE central 60 external corner  L182 x p. 92 x H. 110	ANGOLO ESTERNO 60 TERMINALE DX o SX end right or left 60 external corner  (Fig. DX / right) L182 x p. 92 x H. 110	ANGOLO INTERNO 60 CENTRALE central 60 internal corner  L214 x p. 101,5 x H. 110	ANGOLO INTERNO 60 TERMINALE DX o SX end right or left 60 internal corner  (Fig. DX / right) L215 x p. 101,5 x H. 110
RECEPTION CENTRALE central reception  L x p. 80,5 x H. 110	RECEPTION TERMINALE DX o SX end right or left reception  (Fig. DX / right) L x p. 80,5 x H. 110	ANGOLO ESTERNO 90 CENTRALE central 90 external corner  L127,5 x p. 139,5 x H. 110	ANGOLO ESTERNO 90 TERMINALE DX o SX end right or left 90 external corner  (Fig. DX / right) L127,5 x p. 139,5 x H. 110	ANGOLO INTERNO 90 CENTRALE central 90 internal corner  L93 x p. 105 x H. 110	ANGOLO INTERNO 90 TERMINALE DX o SX end right or left 90 internal corner  (Fig. DX / right) L93 x p. 105 x H. 110	ANGOLO ESTERNO 60 CENTRALE central 60 external corner  L176 x p. 92 x H. 110	ANGOLO ESTERNO 60 TERMINALE DX o SX end right or left 60 external corner  (Fig. DX / right) L176 x p. 92 x H. 110	ANGOLO INTERNO 60 CENTRALE central 60 internal corner  L214 x p. 101,5 x H. 110	ANGOLO INTERNO 60 TERMINALE DX o SX end right or left 60 internal corner  (Fig. DX / right) L215 x p. 101,5 x H. 110
MODULO CENTRALE central module  L120 x p. 95 x H. 72	MODULO TERMINALE DX o SX end right or left module  (Fig. DX / right) L124 x p. 95 x H. 72	ANGOLO ESTERNO 60 CENTRALE central 60 external corner  L171 x p. 107 x H. 72	ANGOLO ESTERNO 60 TERMINALE DX o SX end right or left 60 external corner  (Fig. DX / right) L178 x p. 107 x H. 72	ANGOLO INTERNO 60 CENTRALE central 60 internal corner  L214 x p. 110,5 x H. 72	ANGOLO INTERNO 60 TERMINALE DX o SX end right or left 60 internal corner  (Fig. DX / right) L215 x p. 110,5 x H. 72	MODULO CENTRALE central module  L120 x p. 95 x H. 72	MODULO TERMINALE DX o SX end right or left module  (Fig. DX / right) L124 x p. 95 x H. 72	ANGOLO ESTERNO 60 CENTRALE central 60 external corner  L171 x p. 107 x H. 72	ANGOLO ESTERNO 60 TERMINALE DX o SX end right or left 60 external corner  (Fig. DX / right) L178 x p. 107 x H. 72
ANGOLO ESTERNO 60 CENTRALE central 60 external corner  (Fig. DX / right) L177 x p. 107 x H. 72	ANGOLO ESTERNO 120 CENTRALE central 120 external corner  L308 x p. 140 x H. 72	ANGOLO ESTERNO 180 CENTRALE central 180 external corner  L367 x p. 184 x H. 72	ANGOLO INTERNO 60 CENTRALE central 60 internal corner  L183,5 x p. 107 x H. 72	ANGOLO ESTERNO 60 TERMINALE DX o SX end right or left 60 external corner  (Fig. DX / right) L184,5 x p. 107 x H. 72					
KIT TERMINALE terminal kit  ART. 749	KIT TERMINALE terminal kit  ART. 834	KIT TERMINALE terminal kit  ART. 854	KIT TERMINALE terminal kit  ART. 835 ART. 836	PARTENZA A MURO CON MASSELO PER MODULI ALTA TERMINALE connection to the wall with cover wood for high modules  L12 x p. 4 x H. 105	RECEPTION LINEARE L144 COMPLETA complete linear reception in 144cms  L144 x p. 80,5 x H. 110	ANGOLO RECEPTION ESTERNO 60 COMPLETO complete 60 external corner reception  L183 x p. 92 x H. 110	ANGOLO RECEPTION ESTERNO 90 COMPLETO complete 90 external corner reception  L180 x p. 180 x H. 110		

FREE-STANDING